FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
1/2/3/4/5
6/7/8/9/0
SOURCE
-/--
REVEAL
SIZE
TXT / PAGE -
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
/ REPEAT
SLEEP
TV / RADIO
INFO
EPG
ASPECT

HOLD / FAV+
RED
GREEN
YELLOW
BLUE
I/II / AUDIO
REC. MENU
PIC. MODE
S. MODE
CH. EDIT
CH. GROUP
SUBTITLE
SUBPAGE / FAV -
SKIP NEXT
SKIP PREV
INDEX / PAGE+
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, REVEAL, SIZE, TXT / PAGE, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / REPEAT, BACK, SLEEP, TV / RADIO, TV/DTV, INFO, EPG, ASPECT, / NET TV, HOLD / FAV+, / SMART, ROJO, VERDE, AMARILLO, AZUL, I/II / AUDIO, REC MENU, PIC MODE, S MODE, CH EDIT, CH GROARRIBA, SUBTITLE, SUBPAGE / FAV, SKIP NEXT, SKIP PREV, INDEX / PAGE+, STOP, REC, REW, PLAY / PAUSE, FWD, .