FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT NEXT
CH. ACCESS
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
INFO
EPG
FAV/TEXT F.P.
ASPECT
TEXT HOLD
RED
GREEN

YELLOW
BLUE
POWER OFF
COMPONENT 1
COMPONENT 2
HDMI 1
HDMI 2
INPUT PC
VIDEO 1
VIDEO 2
VIDEO 3
VIDEO 4
POWER ON
SKIP NEXT
SKIP PREV
N
DIRECT TV REC.
TEXT INDEX
STOP
REC
REW
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT NEXT, / SOURCE, CH ACCESS, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, INFO, EPG, FAV/TEXT FP, FAV, ASPECT, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, POWER OFF, COMPONENT 1, COMPONENT 2, HDMI 1, HDMI 2, INPUT PC, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, POWER ON, 0SKIP NEXT, SKIP PREV, DIRECT TV REC, TV/DTV, TEXT INDEX, STOP, REC, REW, FWD, .