FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / OFF
MUTE
DVD MENU
EXIT
1/2/3/4/5
6/7/8/9/0
uMUSIC
PLAYLIST
WHOLE CD
ENCORE
SETTINGS
CD #
VOLUME+
VOLUME-
TRK./CHAP./PR./CH. +
TRK./CHAP./PR./CH. -
UP / TUNE UP
DOWN / TUNE DOWN
LEFT
RIGHT
ENTER
REPEAT
SYSTEM
INFO
LIBRARY

SHUFFLE
PAUSE
STOP
SKIP/SEEK PREV.
PLAY
SKIP/SEEK NEXT
MUTE ALL
AUX
CBL / SAT
CD / DVD
STORED
FM / AM
TV
VCR
RATING-
RATING+

ON / OFF, POWER, MUTE, DVD MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0uMUSIC, PLAYLIST, WHOLE CD, ENCORE, SETTINGS, VOLUME+, VOL+, VOLUME, VOL, TRK/CHAP/PR/CH +, TRK/CHAP/PR/CH, ARRIBA / TUNE ARRIBA, ABAJO / TUNE, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SYSTEM, TV/DTV, INFO, LIBRARY, EPG, SHUFFLE, FAV, PAUSE, STOP, SKIP/SEEK PREV, VERDE, PLAY, AMARILLO, SKIP/SEEK, NEXT, AZUL, MUTE ALL, AUX, CBL / SAT, CD / DVD, STOROJO, FM / AM, VCR, RATING, RATING+, .