FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER ON	MEMORY
MUTING	DIMMER
MENU	OPEN / CLOSE
CLEAR	PAUSE
1/2/3/4/5	STOP
6/7/8/9/0	REW
INPUT SELECTOR DVD	PLAY
+10	FWD
DISPLAY	POWER STANDBY
ZOOM	AUDIO
ANGLE	VIDEO 1
SUBTITLE	VIDEO 2
VOLUME+	TAPE
VOLUME-	TUNER
SKIP NEXT	INPUT SELECTOR TV
SKIP PREV.	RANDOM
UP	SETUP
DOWN	CHANNEL-
LEFT	CHANNEL+
RIGHT	REPEAT
ENTER	A-B
RETURN	TITLE
SLEEP	SLOW
SURROUND MODE	
SEARCH	

POWER ON, POWER, MUTING, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECTOR DVD, DISPLAY, ZOOM, ANGLE, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, SURROUND MODE, TV/DTV, SEARCH, INFO, MEMORY, EPG, DIMMER, FAV, OPEN / CLOSE, PAUSE, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, POWER STANDBY, AUDIO, VIDEO 1, VIDEO 2, TAPE, TUNER, INPUT SELECTOR TV, RANDOM, SETARRIBA, CHANNEL, CHANNEL+, REPEAT, TITLE, SLOW, .