FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER	REW
MUTE	PLAY
HOME	FWD
EXIT	TIMER ON/OFF
1/2/3/4/5	SOUND
6/7/8/9/0	RDS PTY
FUNCTION	SPEED / CD REC
DVD/DISC SKIP	REPEAT
RDS DISPLAY	TIMER CLOCK
EQ.	RED / A / DISPLAY
VOL+	GREEN / B / MO/ST
VOL-	YELLOW / C
SKIP NEXT	BLUE / D
SKIP PREV.	
UP	
DOWN	
LEFT	
RIGHT	
ENTER	
/ RETURN	
SLEEP	
INFO	
PAUSE	
STOP	
USB REC	

POWER, MUTE, HOME, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, DVD/DISC, SKIP, RDS DISPLAY, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, SLEEP, INFO, PAUSE, STOP, USB REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TIMER ON/OFF, SOUND, RDS PTY, SPEED, / CD REC, REPEAT, TIMER CLOCK, ROJO / A / DISPLAY, VERDE / B / MO/ST, AMARILLO / C, AZUL / D, .