FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
DISC MENU
1/2/3/4/5
6/7/8/9/0
AMBISOUND
AUDIO SYNC.
DISPLAY
ZOOM
ANGLE
SUBTITLE
VOL+
VOL-
UP
DOWN
LEFT
RIGHT
OK
⮌ / TITLE
BASS / TREBLE
PROGRAM / SELECT
SOUND
OPEN / CLOSE
PAUSE
STOP

REW / SKIP PREV.
PLAY
FFW / SKIP NEXT
AUDIO
AUX
DIGITAL IN
DISC
DOCK
MP3 / LINE-IN
RADIO
TV
USB
SETUP
REPEAT / SHUFFLE

POWER, MUTE, DISC MENU, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AMBISOUND, AUDIO SYNC, DISPLAY, ZOOM, ANGLE, SUBTITLE, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, TITLE, BACK, BASS / TREBLE, TV/DTV, PROGRAM, / SELECT, EPG, SOUND, FAV, OPEN / CLOSE, PAUSE, STOP, REW / SKIP PREV, VERDE, PLAY, AMARILLO, FFW, / SKIP NEXT, AZUL, AUDIO, AUX, DIGITAL IN, DISC, DOCK, MP3 / LINE, RADIO, USB, SETARRIBA, REPEAT / SHUFFLE, .