FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU / PBC
1/2/3/4/5
6/7/8/9/0
SOURCE
10+
DISPLAY
ZOOM / MEMO
ANGLE
SUBT. / RIP.
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
A-B
CHANNEL
SEARCH
PRO LOGIC II
HDMI

OPEN / CLOSE
PAUSE
STOP
REV.
PLAY
FWD
AUDIO
DVD / USB
SETUP
TUNER-
TUNER+
REPEAT
TITLE / BAND
DIRECT PLAY

POWER, MUTE, MENU / PBC, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / AV, 10+, DISPLAY, ZOOM / MEMO, ANGLE, SUBT /, RIP, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, CHANNEL, TV/DTV, SEARCH, INFO, PRO LOGIC II, EPG, HDMI, FAV, OPEN / CLOSE, PAUSE, STOP, REV, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, DVD / USB, SETARRIBA, TUNER, TUNER+, REPEAT, TITLE / BAND, TV/DTV, DIRECT PLAY, .