FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
/ AUDIO
MENU
TOP MENU
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
MARKER / SP/LP
BLANK / SEARCH
ZOOM
/ ANGLE
/ SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK / ENTER
RETURN
CLK/CNT / DISPLAY
TV / VCR
i / SET UP
SHOW VIEW / PROGR.
RANDOM

EJECT / OPEN/CLOSE
PAUSE / ST.
STOP
REC / OTR.
REW
PLAY
FWD
VCR MENU
CLEAR / COUNT. RESET
DVD
VCR
SEARCH
INSTANT REPLAY
A-B RPT. / INST. SKIP
PR / TRK+
PR / TRK -
REPEAT
AUTO TRK
SLOW

POWER, / AUDIO, MUTE, MENU, TOP, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / SOURCE, MARKER / SP/LP, BLANK / SEARCH, ZOOM, / ANGLE, / SUBTITLE, SKIP, NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, OK / ENTER, RETURN, BACK, CLK/CNT, / DISPLAY, SLEEP, TV / VCR, TV/DTV, i / SET ARRIBA, INFO, SHOW VIEW / PROGR, EPG, RANDOM, FAV, EJECT / OPEN/CLOSE, / NET TV, PAUSE / ST, STOP, / SMART, REC / OTR, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, VCR MENU, CLEAR / COUNT RESET, DVD, VCR, SEARCH, INSTANT REPLAY, B RPT / INST, SKIP, DERECHA, PR / TRK+, PR / TRK, REPEAT, AUTO, TRK, SLOW, .