FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
/ MUTE
/ MENU
EXIT
1/2/3/4/5
6/7/8/9/0
/ SOURCE
CH. LIST
HOLD
SIZE
SUB CODE
TEXT / MIX
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
⮌ / RETURN
T. SHIFT
ECO
INFO

EPG
FAV
MEDIA
STILL / REVEAL
HI SMART@
RED
GREEN
YELLOW
BLUE
LANGUAGE / I/II
CANCEL
P. MODE
S. MODE
PVR
SUBT
SKIP PREV/NEXT
PRE – CH
INDEX
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, / MUTE, MUTE, / MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, SOURCE, / SOURCE, CH LIST, HOLD, SIZE, SUB CODE, TEXT / MIX, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / RETURN, BACK, T SHIFT, SLEEP, ECO, TV/DTV, INFO, EPG, FAV, MEDIA, / NET TV, STILL / REVEAL, HI SMART, / SMART, ROJO, VERDE, AMARILLO, AZUL, LANGUAGE / I/II, CANCEL, P MODE, S MODE, PVR, SUBT, SKIP PREV/NEXT, SHIFT, + P, PRE, INDEX, PAUSE, STOP, REC, REW, PLAY, FWD, .