FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
/ HOME
DELETE
1/2/3/4/5
6/7/8/9/0
SOURCE
CAPS / NUM
/ ZOOM
ANGLE
A / SUBTITLE
VOLUME/PAGE +
VOLUME/PAGE -
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
/ TIME SEEK
TV MODE
i / INFO
/ FILE MODE

USB/DVDROM EJECT
PAUSE
STOP
REV.
PLAY
FWD
/ AUDIO
/ MENU
SETUP
/ REPEAT
/ TITLE
SLOW
BT / SUSPEND

POWER, MUTE, / HOME, MENU, DELETE, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, CAPS / NUM, / ZOOM, ANGLE, A / SUBTITLE, VOLUME/PAGE +, VOL+, VOLUME/PAGE, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, / TIME SEEK, SLEEP, TV MODE, TV/DTV, i / INFO, INFO, / FILE MODE, USB/DVDROM, EJECT, PAUSE, STOP, REV, VERDE, PLAY, AMARILLO, FWD, AZUL, / AUDIO, / MENU, SETARRIBA, / REPEAT, / TITLE, SLOW, BT / SUSPEND, .