FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
CD DIRECT 1
CD DIRECT 2
CD DIRECT 3
AUX
CD
CDR
TAPE ½
TUNER
BALANCE L.
BALANCE R.
DISPLAY
FLAT
SIDE
LOUDNESS
VOLUME+
VOLUME-
SKIP NEXT
SKIP PREV.
BASS+
BASS-
TREBLE-
TREBLE+
REPEAT

SLEEP
INC. SURR.
PROGRAM
SHUFFLE
PAUSE
STOP
REW
PLAY
FWD
TIMER
TAPE PAUSE
TAPE STOP
TAPE REW
TAPE PLAY
TAPE FWD

POWER, MUTE, CD DIRECT 1, CD DIRECT 2, CD DIRECT 3, AUX, CDR, TAPE, TUNER, BALANCE L, BALANCE R, DISPLAY, FLAT, SIDE, LOUDNESS, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, BASS+, BASS, ABAJO, TREBLE, IZQUIERDA, TREBLE+, DERECHA, REPEAT, BACK, SLEEP, INC SURR, INFO, PROGRAM, EPG, SHUFFLE, FAV, PAUSE, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TIMER, TAPE PAUSE, TAPE STOP, TAPE REW, TAPE, TAPE FWD, .