FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY – ON
AUDIO
SYSTEM
DISP. / STATUS / EXIT
1/2/3/4/5
6/7/8/9/0
DVD
+10
CLEAR
ZOOM
ANGLE
SUBTITLE
REPEAT A – B
REPEAT
SKIP NEXT / P+
SKIP PREV / P -
UP
DOWN
LEFT
RIGHT
OK
RETURN
MODE
TITLE
DISC MENU

SEARCH / MODE
OPEN / CLOSE
PAUSE
STOP
REW
PLAY
FWD
VC
AUDIO
VCR MENU
DISPL. STATUS / EXIT
1/2/3/4/5
6/7/8/9/0
VCR
SV / V+
CLEAR
ZOOM / TIMER SET
SUBTITLE
REPEAT A – B
SKIP NEXT / P+
SKIP PREV / P -
DOWN
UP
LEFT

RIGHT
OK
SLOW
INDEX / SKIP
SYSTEM
SEARCH MODE
EJECT
PAUSE
STOP
REC
REW
PLAY
FWD

STANDBY, POWER, AUDIO, MUTE, SYSTEM, MENU, DISP / STATUS / EXIT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD, / SOURCE, CLEAR, ZOOM, ANGLE, SUBTITLE, REPEAT, VOL+, REPEAT, VOL, SKIP NEXT / P+, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, MODE, TV/DTV, TITLE, INFO, DISC MENU, EPG, SEARCH / MODE, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, VCR, VCR MENU, DISPL STATUS, / EXIT, 1/2/3/4/5, 0 6/7/8/9/, 0VCR, SHIFT, SV / V+, ZOOM / TIMER SET, VOL+, NEXT, SLOW, SLEEP, INDEX / SKIP, SEARCH MODE, EJECT, REC, ROJO, .