FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER	REC
/ AUDIO	REV.
TOP MENU	PLAY
CLEAR	FWD
1/2/3/4/5	DISC MENU
6/7/8/9/0	HDMI
INPUT SELECT	DVD
DUBBING	HDD
DISPLAY	PROG. -
ZOOM	PROG. +
SETUP	VARIABLE REPLAY
SKIP NEXT	VARIABLE SKIP
SKIP PREV.	REPEAT
UP	REC. MODE
DOWN	1.3x/0.8x PLAY
LEFT	
RIGHT	
ENTER	
RETURN	
TIME SLIP	
SAT. LINK	
TIMER PROG.	
OPEN / CLOSE	
PAUSE	
STOP	

POWER, / AUDIO, MUTE, TOP MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, DUBBING, DISPLAY, ZOOM, SETARRIBA, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIME, SLIP, SLEEP, SAT, LINK, TV/DTV, TIMER PROG, EPG, OPEN / CLOSE, PAUSE, STOP, REC, ROJO, REV, VERDE, PLAY, AMARILLO, FWD, AZUL, DISC MENU, HDMI, DVD, HDD, PROG, PROG +, VARIABLE REPLAY, VARIABLE SKIP, REPEAT, REC MODE, 13x/08x, .