FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / SOURCE
MUTE
MENU
RESTORER
DVD
DVR
HDP
iPod
SAT / CBL
TUNER
TV
V.AUX
VCR
SOURCE SELECT
SPEAKERS
V. SEL.
DIMMER
SETUP
CH. LEVEL
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN

LEFT
RIGHT
ENTER
RETURN
SLEEP
BAND
STATUS
MEMORY
MODE
SHIFT
PAUSE
STOP
REW
PLAY
FWD
OFF
QUICK SELECT 1 (DVD)
Q. SELECT 2 (SAT/CBL)
Q. SELE. 3 (VCR/iPod)
INPUT MODE
DYN. EQ.
DYN. VOL.
PRESET NEXT
PRESET PREV
CHANNEL+

CHANNEL -
SEARCH
CINEMA
D. / ST.
SIMU.
STD.
MULT.-EQ.

iPo

MENU
DOWN
UP
LEFT
RIGHT
ENTER
MEMORY
STOP

CHANNEL, SEARCH, INFO, CINEMA, D / ST, ROJO, SIMU, VERDE, STD, AMARILLO, MULT, AZUL, iPod, MENU, ABAJO, IZQUIERDA, DERECHA, ENTER, MEMORY, EPG, STOP, ON / SOURCE, POWER, MUTE, RESTORER, EXIT, DVD, DVR, HDP, SAT, / CBL, TUNER, VAUX, VCR, SOURCE SELECT, / SOURCE, SPEAKERS, V SEL, DIMMER, SETARRIBA, CH LEVEL, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP, PREV, RETURN, BACK, SLEEP, BAND, TV/DTV, STATUS, MODE, FAV, SHIFT, / NET TV, PAUSE, / SMART, REW, PLAY, FWD, OFF, QUICK SELECT 1 DVD, Q SELECT 2 SAT/CBL, Q SELE 3 VCR/iPod, INPUT MODE, DYN EQ, DYN VOL, PRESET, NEXT, CHANNEL+, .