FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STANDBY
MUTING
HOME
1/2/3/4/5
6/7/8/9/0
SP LAYOUT
D. TUN.
DISPLAY
SETUP
DIMMER
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
PAUSE
REW
PLAY
FWD

AUDIO
AUX
BD / DVD
CBL / SAT
GAME
PC
PORT
TUNER
TV / CD
VCR / DVR
VIDEO
CH/DISC -
CH/DISC +
LISTEN. MODE – GAME
LI. MODE – MOVIE/TV
LIST. MODE – MUSIC
LISTEN. MODE – THX

ON / STANDBY, POWER, MUTING, MUTE, HOME, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SP LAYOUT, D TUN, DISPLAY, SETARRIBA, DIMMER, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, PAUSE, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, AUX, BD / DVD, CBL / SAT, GAME, PORT, TUNER, / CD, VCR / DVR, VIDEO, CH/DISC, CH/DISC +, LISTEN MODE, ROJO, MODE, MOVIE, /TV, LIST, MUSIC, LISTEN, THX, .