FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
MENU / PLAY LIST
CANCEL
1/2/3/4/5
6/7/8/9/0
TV/AV
CH. SELECT - TEST
FL DISPLAY - DIMMER
ZOOM
FM MODE – SETUP
SUBWOOFER LEVEL
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
DOLBY PL.
GROUP

POSITION MEMORY
S. SRND.
PAUSE
STOP
SLOW/SEARCH REW
PLAY
SLOW/SEARCH FWD
AUDIO
TOP MENU / DIR. NAV.
VCR / AUX
DVD / CD
TUNER / BAND
TV
2nd ENTER
REPEAT
C. FOCUS
SFC
C.S.M.
PLAY MO. – MIX 2 CH.

POWER, MUTING, MUTE, MENU / PLAY LIST, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0TV/AV, / SOURCE, CH SELECT, TEST, FL DISPLAY, DIMMER, ZOOM, FM MODE, SETARRIBA, SUBWOOFER LEVEL, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, DOLBY PL, TV/DTV, GROARRIBA, INFO, POSITION MEMORY, EPG, S SRND, FAV, PAUSE, STOP, / SMART, SLOW/SEARCH REW, VERDE, PLAY, AMARILLO, SLOW/SEARCH FWD, AZUL, AUDIO, TOP MENU / DIR NAV, VCR / AUX, DVD / CD, TUNER / BAND, REPEAT, FOCUS, SFC, CSM, MIX 2 CH, .