FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
DELETE
1/2/3/4/5
6/7/8/9/0
+10
DISPLAY
PLAY MODE
D.BASS
REMASTER
VOL+
VOL-
SKIP NEXT TRACK
SKIP PREV TRACK
USB PLAY
USB PAUSE
PREV ALBUM
NEXT ALBUM
PRESET EQ
PROGRAM
REPEAT
MANUAL EQ
SLEEP
DISC
PLAY REC

CD PAUSE
STOP
REW
CD PLAY
FWD
DIMMER
INPUT DISC
INPUT MUSIC P
INPUT TAPE
INPUT TUNER
INPUT USB
CLEAR
AUTO OFF
CLOCK TIMER
PLAY TAPE

POWER, MUTE, DELETE, EXIT, 1/2/3/4/5, 6/7/8/9/, DISPLAY, PLAY MODE, DBASS, REMASTER, VOL+, VOL, SKIP NEXT, TRACK, SKIP PREV TRACK, USB PLAY, USB PAUSE, ABAJO, PREV ALBUM, IZQUIERDA, NEXT ALBUM, DERECHA, PRESET EQ, FAV, PROGRAM, EPG, REPEAT, BACK, MANUAL EQ, INFO, SLEEP, DISC, TV/DTV, PLAY REC, ROJO, CD PAUSE, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DIMMER, INPUT DISC, INPUT MUSIC P, INPUT TAPE, INPUT TUNER, INPUT USB, CLEAR, AUTO OFF, CLOCK TIMER, PLAY TAPE, .