FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
AUDIO
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
OUTPUT SELECT
+10
ZOOM
ANGLE
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
RETURN
TIMER SET
VCR / TV
MARKER
PAUSE
STOP
REW

PLAY
F.F.
DISC MENU
DVD
VCR
SETUP
CHANNEL+
CHANNEL -
REPEAT
REPEAT A – B
MODE
VCR PAUSE
VCR STOP
VCR REC/OTR.
VCR REW
VCR PLAY
VCR F.F.

POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0OUTPUT SELECT, / SOURCE, ZOOM, ANGLE, SUBTITLE, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, TIMER SET, SLEEP, VCR, / TV, TV/DTV, MARKER, FAV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, AZUL, DISC MENU, DVD, SHIFT, SETARRIBA, CHANNEL+, CHANNEL, REPEAT, REPEAT, MODE, VCR PAUSE, VCR STOP, VCR REC/OTR, ROJO, VCR REW, VCR PLAY, VCR FF, .