FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STANDBY
MUTE
MENU
CLEAR / DEL.
1/2/3/4/5
6/7/8/9/0
SOURCE
+10
TIME / DISPLAY
REMOTE / BROWSE
DAB / RDS
FOLDER MODE
VOLUME+
VOLUME -
SKIP NEXT / CH+
SKIP PREV / CH -
UP / FOLDER+
DOWN / FOLDER -
LEFT
RIGHT
ENTER / MEMO.
REPEAT
SLEEP
TUNER
DIMMER

PROG. / DIRECT
RANDOM
USB/iPod PLAY/PAUSE
STOP
REW / TU -
CD PLAY/PAUSE
FWD / TU+
CLOCK
SDB / TONE
DOCK PLAY/PAUSE

ON / STANDBY, POWER, MUTE, MENU, CLEAR / DEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, SOURCE, TIME / DISPLAY, REMOTE / BROWSE, DAB / RDS, FOLDER MODE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT / CH+, SKIP, PREV, / CH, ARRIBA / FOLDER+, ABAJO /, FOLDER, ABAJO, IZQUIERDA, DERECHA, ENTER / MEMO, REPEAT, BACK, SLEEP, TUNER, TV/DTV, DIMMER, INFO, PROG / DIRECT, EPG, RANDOM, FAV, USB/iPod PLAY/PAUSE, STOP, / SMART, REW /, VERDE, PLAY/PAUSE, AMARILLO, FWD / TU+, AZUL, CLOCK, SDB / TONE, DOCK PLAY/PAUSE, .