FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER	PLAY
MUTE	TIMER
MENU	AUDIO
EXIT	IPOD MENU
1/2/3/4/5	IPOD SHUFFLE
6/7/8/9/0	IPOD REPEAT
INPUT DVD	IPOD UP / DOWN
INPUT IPOD	IPOD PAUSE
DISPLAY	IPOD PLAY
TOP MENU	IPOD ENTER
OPTION	IPOD PREV/NEXT TRACK
ON SCREEN	PURE DIRECT
VOL+/VOL-	MONO
PRESET UP/ SKIP NEXT CHAP	DIMMER
PRESET UP/ SKIP NEXT CHAP	ZOOM
REPEAT	SETUP
SLEEP	SUBTITLE
INPUT USB	TUNE+ / TUNE-
RANDOM	INPUT AUX
ANGLE	IPOD PAUSE
MEMORY	BAND
EJECT	UP/DOWN
PAUSE	LEFT/RIGHT
STOP	OK
REW/FWD	

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, INPUT, DVD, INPUT IPOD, DISPLAY, TOP MENU, OPTION, ON SCREEN, VOL+/VOL, PRESET, ARRIBA/ SKIP, NEXT CHAP, REPEAT, BACK, SLEEP, INPUT USB, TV/DTV, RANDOM, INFO, ANGLE, FAV, MEMORY, EPG, EJECT, PAUSE, STOP, REW/FWD, VERDE/ AZUL, PLAY, AMARILLO, TIMER, AUDIO, IPOD MENU, IPOD SHUFFLE, IPOD REPEAT, IPOD ARRIBA / ABAJO, ARRIBA/ABAJO, IPOD PAUSE, IPOD PLAY, IPOD ENTER, IPOD PREV/NEXT, TRACK, VERDE/, AZUL, PURE DIRECT, MONO, DIMMER, ZOOM, SETARRIBA, HSITF+, SUBTITLE, TUNE+ / TUNE, V+/V, INPUT AUX, BAND, EPG, IZQUIERDA/DERECHA, .