FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
MUTING
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
PRO LOGIC
EFFECT
DISPLAY
ZOOM
ANGLE
SUBTITLE
VOLUME+
VOLUME-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
D.R.C.
SOUND

PROGRAM
DSP MODE
PAUSE
STOP
REW
PLAY
FWD
AUDIO/FM MODE
SETTING
AUX
DVD
FM / AM
SETUP
STEP
SLOW
REMAIN

STANDBY / ON, POWER, MUTING, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0PRO LOGIC, EFFECT, DISPLAY, ZOOM, ANGLE, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, DRC, TV/DTV, SOUND, INFO, PROGRAM, EPG, DSP MODE, FAV, PAUSE, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO/FM MODE, SETTING, AUX, DVD, FM / AM, SETARRIBA, STEP, SLOW, REMAIN,
.