FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
◯)) / AUDIO
⌂ / HOME
CLEAR
1/2/3/4/5
6/7/8/9/0
AV / INPUT
MENU / LIST
DISPLAY
SUBTITLE
TEXT
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TIME SHIFT
TV / DVD
TITLE
EPG
FAV
OPEN / CLOSE

PAUSE / STEP
STOP
REC
SCAN REW
PLAY
SCAN FWD
DVD
HDD
PR./CH+
PR./CH -
REPEAT
✓ / MARKER
RED
GREEN
YELLOW
BLUE

POWER, / AUDIO, MUTE, / HOME, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV / INPUT, SOURCE, MENU / LIST, DISPLAY, SUBTITLE, TEXT, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIME SHIFT, SLEEP, TV / DVD, TV/DTV, TITLE, INFO, EPG, FAV, OPEN / CLOSE, / NET TV, PAUSE / STEP, STOP, / SMART, REC, ROJO, SCAN REW, VERDE, PLAY, AMARILLO, SCAN FWD, AZUL, DVD, HDD, PR/, CH+, REPEAT, / MARKER, .