FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
1/2/3/4/5
6/7/8/9/0
FUNCTION
CH. SELECT
DISP. MODE
ATT.
DSP MODE
TEST TONE
VOL+
VOL-
CHANNEL+
CHANNEL-
UP
DOWN
LEFT
RIGHT
ENTER
MIDNIGHT
SIG. SELECT
FL DIMMER
MPX
DOLBY
CH. LEVEL -

CH. LEVEL +
EFFECT-
EFFECT+
VCR 1
VCR 2
CD
DVD / LD
MD / TAPE
TV CONTROL
TUNER
TV / SAT
CLASS
DIRECT
FQ.-
FQ.+

POWER, MUTING, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTION, CH SELECT, DISP MODE, ATT, DSP MODE, TEST TONE, VOL+, VOL, CHANNEL+, CHANNEL, ABAJO, IZQUIERDA, DERECHA, ENTER, MIDNIGHT, SLEEP, SIG, SELECT, TV/DTV, FL DIMMER, INFO, MPX, EPG, DOLBY, FAV, CH LEVEL, ROJO, CH LEVEL +, VERDE, EFFECT, AMARILLO, EFFECT+, AZUL, VCR 1, VCR 2, DVD / LD, MD / TAPE, TV CONTROL, TUNER, TV / SAT, CLASS, DIRECT, FQ+, .