FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
AUDIO
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
DVD
+10
DISPLAY
ZOOM
SETUP
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SURROUND
MODE
DISC NAVIGATION
SEARCH MODE
TOP MENU

OPEN / CLOSE
PAUSE
STOP
REW
PLAY
FWD
VCR
ANGLE
REPEAT
A – B
VC
TIMER
AUDIO
MENU
C. RESET
1/2/3/4/5
6/7/8/9/0
+10
DISPLAY
SPEED
SLOW
PROG.+
PROG. -
UP

DOWN
LEFT
RIGHT
SEARCH MODE
SHOW VIEW
QIUCK – FIND
EJECT
PAUSE
STOP
RECORD
REW
PLAY
FWD

POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD, SOURCE, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SURROUND, SLEEP, MODE, TV/DTV, DISC NAVIGATION, INFO, SEARCH MODE, EPG, TOP MENU, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, VCR, SHIFT, ANGLE, REPEAT, TIMER, C RESET, 0+1, SPEED, SLOW, PROG+, PROG, SHOW VIEW, QIUCK, FIND, EJECT, RECORD, ROJO, .