FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
SYSTEM SETUP
CLEAR
1/2/3/4/5
6/7/8/9/0
+10
NETWORK SETUP
SDB. TONE
VOLUME+
VOLUME -
SKIP NEXT / CH+
SKIP PREV / CH -
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
MODE
INFO
PROGRAM
RANDOM
PAUSE

STOP
REW / TUNE -
PLAY
FWD / TUNE+
AMP – TUNER
AMP – ANALOG IN
AMP – DIGITAL IN
NETW. – INTERNET RA.
NETW. – ONLINE MUS.
NETW. – MUSIC SERV.
NETWORK – iPod/USB
CD – CD
CD – iPod/USB
CLOCK
DIMMER

POWER, MUTE, SYSTEM SETARRIBA, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, NETWORK SETARRIBA, SDB TONE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT / CH+, SKIP PREV / CH, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, MODE, TV/DTV, INFO, PROGRAM, EPG, RANDOM, FAV, PAUSE, STOP, / SMART, REW / TUNE, VERDE, PLAY, AMARILLO, FWD / TUNE+, AZUL, AMP, TUNER, ANALOG IN, DIGITAL IN, NETW, INTERNET RA, NETW, ONLINE MUS, MUSIC, SERV, NETWORK, iPod/USB, CLOCK, DIMMER, .