FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
1 / SELECT
2 / SELECT ALL
3/4/5/6/7
8 / REFRESH
9
0 / SLEEP
DEVICE
SEARCH
SCR. SIZE
SETUP
SUBTITLE
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
⮌ / SLOW
TV OUT

INFO
BRT. CONT.
./ / BOOKMARK
STOP
REW
PLAY / PAUSE
FWD
AUDIO
MUSIC
MOVIE
PHOTO
ALL MEDIA
ANGLE
REPEAT
A-B REPEAT
TITLE

POWER, MUTE, MENU, 1 / SELECT, 2 / SELECT ALL, 3/4/5/6/7, 8 / REFRESH, 0 / SLEEP, 0DEVICE, SOURCE, SEARCH, SCR SIZE, SETARRIBA, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, / SLOW, BACK, TV OUT, TV/DTV, INFO, BRT CONT, EPG, / / BOOKMARK, FAV, STOP, / SMART, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, AUDIO, MUSIC, MOVIE, PHOTO, ALL MEDIA, ANGLE, REPEAT, B REPEAT, SLEEP, TITLE, .