FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STANDBY
MUTING
1/2/3/4/5
6/7/8/9/0
D. TUN.
DISPLAY
SETUP
DIMMER
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
PAUSE
REW
PLAY
FWD
AUDIO
AUX

DVD / BD
CBL / SAT
GAME
TV / TAPE
PORT
TUNER
CD
VCR / DVR
VIDEO
CH/DISC -
CH/DISC +
LISTEN. MODE – GAME
LI. MODE – MOVIE/TV
LIST. MODE – MUSIC
LIST. MODE – STEREO

ON / STANDBY, POWER, MUTING, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0D TUN, DISPLAY, SETARRIBA, DIMMER, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, PAUSE, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, AUX, DVD / BD, CBL / SAT, GAME, TV / TAPE, PORT, TUNER, VCR / DVR, VIDEO, CH/DISC, CH/DISC +, LISTEN MODE, ROJO, LI MODE, MOVIE, /TV, LIST MODE, MUSIC, STEREO, .