FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
AUDIO
MENU / THUMB./LIST
CANCEL
1/2/3/4/5
6/7/8/9/0
10
+10
DISPLAY / DIMMER
ZOOM
ANGLE / SLIDE EFFECT
SUBTITLE
SKIP NEXT
SKIP PREVIOUS
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
ON SCREEN
TITLE / GROUP
TOP MENU
SOUND EFFECT
PAUSE

STOP
REW / SLOW-
PLAY
FWD / SLOW+
CLEAR
VFP / I/P
SET UP
SELECT
↻

STANDBY / ON, POWER, AUDIO, MUTE, MENU / THUMB/LIST, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV, DISPLAY / DIMMER, ZOOM, ANGLE / SLIDE EFFECT, SUBTITLE, SKIP NEXT, SKIP PREVIOUS, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, ON SCREEN, TV/DTV, TITLE / GROARRIBA, INFO, TOP MENU, EPG, SOUND EFFECT, FAV, PAUSE, STOP, REW / SLOW, VERDE, PLAY, AMARILLO, FWD / SLOW+, AZUL, CLEAR, VFP / I/P, SET ARRIBA, SELECT, .