FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
AUDIO
MENU
CLEAR
1 / TRACKING-
2
3 / TRACKING+
4/5/6
7/8/9/0
INPUT
SEARCH
DISPLAY
ZOOM
SETUP
SUBTITLE
SKIP NEXT
SKIP PREV.
UP / PR.+
DOWN / PR.-
LEFT
RIGHT
OK / ENTER
LAST CH.
TV / VCR
TITLE / PBC

PROGRAM
MARK
OPEN / CLOSE
SPEED
STOP
REC
REW
PLAY / PAUSE
FF.
SYSTEM
VCR
DVD
3D
ANGLE
REPLAY
CM-SKIP
REPEAT
A-B

POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1 / TRACKING, 3 / TRACKING+, 4/5/6, 7/8/9/, 07/8/9/, 0INPUT, / AV, SEARCH, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, SKIP NEXT, SKIP PREV, ARRIBA / PR+, ABAJO / PR, ABAJO, IZQUIERDA, DERECHA, OK / ENTER, LAST CH, BACK, TV / VCR, TV/DTV, TITLE / PBC, INFO, PROGRAM, EPG, MARK, FAV, OPEN / CLOSE, SPEED, STOP, REC, ROJO, REW, VERDE, PLAY / PAUSE, AMARILLO, AZUL, SYSTEM, VCR, DVD, ANGLE, REPLAY, SKIP, REPEAT, SLEEP, .