FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
AUDIO
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT / SOURCE
VARIABLE REPLAY
SEARCH MODE
RECORD MODE
RECORD MONITOR
TIMER PROGRAM
P+
P-
UP
DOWN
LEFT
RIGHT
OK
CLEAR
DUBBING MENU
INFO
VARIABLE SKIP
OPEN/CLOSE
PAUSE

STOP
DVD REC
HDD REC
REW
PLAY
FWD
TOP MENU
INPUT DVD
INPUT HDD
INPUT VCR
SETUP
SKIP NEXT CHAP
SKIP PREV CHAP

POWER, AUDIO, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT /, SOURCE, VARIABLE REPLAY, SEARCH MODE, RECORD MODE, RECORD MONITOR, TIMER PROGRAM, ABAJO, IZQUIERDA, DERECHA, CLEAR, BACK, DUBBING MENU, EPG, INFO, VARIABLE SKIP, FAV, OPEN/CLOSE, PAUSE, STOP, DVD REC, ROJO, HDD REC, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TOP MENU, INPUT, DVD, INPUT HDD, INPUT VCR, SETARRIBA, SKIP NEXT, CHAP, SKIP PREV CHAP, .