FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
AUDIO
/ HOME MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
OUTPUT RESOL. DOWN
OUTPUT RESOL. UP
DISPLAY
ANGLE
/ TOOLS
SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
/ RETURN
PLAY MODE
FL DIMMER
TOP MENU
HOME MEDIA GALLERY
OPEN / CLOSE

PAUSE
STOP
REW / STEP BACK
PLAY
FWD / STEP FWD
MENU / POPUP MENU
SECONDARY VIDEO
SECONDARY AUDIO
VIDEO SELECT
VIDEO ADJUST
RED
GREEN
YELLOW
BLUE

STANDBY / ON, POWER, AUDIO, MUTE, / HOME MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0OUTPUT RESOL, ABAJO, OUTPUT RESOL ARRIBA, DISPLAY, ANGLE, / TOOLS, SUBTITLE, SKIP NEXT, SKIP PREV, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, PLAY MODE, TV/DTV, FL DIMMER, INFO, TOP MENU, EPG, HOME MEDIA GALLERY, FAV, OPEN / CLOSE, PAUSE, STOP, REW / STEP BACK, VERDE, PLAY, AMARILLO, FWD / STEP FWD, AZUL, MENU / POPARRIBA MENU, SECONDARY, VIDEO, SECONDARY AUDIO, VIDEO SELECT, VIDEO ADJUST, ROJO, .