FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON – DVD
AUDIO
MENU
CANCEL
1/2/3/4/5
6/7/8/9
0 / AUX
TV / INPUT
REC. LINK
DISPLAY
ANGLE / LIVE CHECK
SET UP
SUBTITLE
TV VOL +
TV VOL -
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TIMER /
VCR PLUS +

ON SCREEN
MEMO. / MARK
REC. MODE / REMAIN
OPEN / CLOSE
PAUSE
STOP / CLEAR
REC
REW / SLOW-
PLAY
FWD / SLOW+
TOP MENU
PROGRESSIVE SCAN
CH-
CH+
PROG.
NAVIGATION

STANDBY/ON, DVD, POWER, AUDIO, MUTE, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9, 0 / AUX, 0TV / INPUT, REC LINK, DISPLAY, ANGLE / LIVE CHECK, SET ARRIBA, SUBTITLE, TV VOL +, VOL+, TV VOL, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIMER /, SLEEP, VCR PLUS +, TV/DTV, ON SCREEN, INFO, MEMO / MARK, EPG, REC MODE / REMAIN, FAV, OPEN / CLOSE, PAUSE, STOP / CLEAR, REC, ROJO, REW / SLOW, VERDE, PLAY, AMARILLO, FWD / SLOW+, AZUL, TOP MENU, PROGRESSIVE SCAN, CH+, PROG, NAVIGATION, .