FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY – ON
MUTE
SYSTEM MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT
DVD
DISPLAY
ZOOM
RANDOM
SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
OK / ENTER
/ RETURN
LOCK
SHOWVIEW / VIDEO+
TITLE
THUMNAIL
MARKER

OPEN / CLOSE
PAUSE / STEP
STOP
REC
REW
PLAY
FWD
TIMER
DISC MENU
ANGLE
REPEAT
REPEAT A-B
CHP. ADD
D. DUBBING
SEARCH
REC MODE

STANDBY, POWER, MUTE, SYSTEM MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, DVD, DISPLAY, ZOOM, RANDOM, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, OK / ENTER, / RETURN, BACK, LOCK, SLEEP, SHOWVIEW, / VIDEO+, TV/DTV, TITLE, INFO, THUMNAIL, EPG, MARKER, FAV, OPEN / CLOSE, PAUSE / STEP, STOP, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TIMER, DISC MENU, ANGLE, REPEAT, REPEAT A, CHP ADD, D DUBBING, SEARCH, REC MODE, .