FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

DV
I/⏻
/ AUDIO
MENU / LIST
CLEAR
1/2/3/4/5
6/7/8/9/0
DVD
VCR
DISPLAY
ZOOM
SETUP
T-SET
INSTANT SKIP
REPEAT
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TIMER PROG.

REC MODE
1.3X / 0.8X / PLAY
DUBBING
TOP MENU
OPEN / CLOSE
PAUSE
STOP
REC
REW
PLAY
FWD
VC
/ AUDIO
SYSTEM
CLEAR
1/2/3/4/5
6/7/8/9/0
DISPLAY
PROG. UP
PROG. DOWN
SLOW
REC MODE
SEARCH
OPEN / CLOSE

PAUSE
STOP
REC
REW
PLAY
FWD

DVD, POWER, / AUDIO, MUTE, MENU / LIST, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD, VCR, DISPLAY, ZOOM, SETARRIBA, SET, INSTANT SKIP, VOL+, REPEAT, VOL, SKIP, NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TIMER PROG, SLEEP, REC MODE, TV/DTV, 13X / 08X / PLAY, INFO, DUBBING, EPG, TOP MENU, FAV, OPEN / CLOSE, PAUSE, STOP, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SYSTEM, 0DISPLAY, PROG ARRIBA, PROG ABAJO, SLOW, SEARCH, .