FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
TV MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
-/--
DISPLAY
SIZE
SUBPAGE
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ENTER
SLEEP
TV/RADIO
INDEX

EPG
FAV
AUTO
HOLD
RED
GREEN
YELLOW
BLUE
AUDIO / NICAM
P. MODE
S. MODE
MEDIA
REVEAL / ZOOM
SUBTITLE
SKIP NEXT
SKIP PREV
FAV - / REPEAT
FAV+
GUIDE
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, DISPLAY, SIZE, SUBPAGE, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, TV/RADIO, TV/DTV, INDEX, INFO, EPG, FAV, AUTO, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO / NICAM, P MODE, S MODE, MEDIA, REVEAL / ZOOM, SUBTITLE, SKIP NEXT, SKIP PREV, FAV, / REPEAT, FAV+, GUIDE, STOP, REC, REW, PLAY / PAUSE, FWD, .