FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY – ON
AUDIO
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
DISPLAY
DUBBING
SETUP
PROG UP
PROG DOWN
UP
DOWN
LEFT
RIGHT
ENTER
↵ / RETURN
TIMER PROG
REC HDD
VARIABLE REPLAY
VARIABLE SKIP
TOP MENU
OPEN / CLOSE - EJECT
PAUSE

STOP
REC MODE
REW
PLAY
FWD
DVD
HDD
VCR
SKIP NEXT
SKIP PREV

STANDBY, POWER, AUDIO, MUTE, DISC MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / SOURCE, DISPLAY, DUBBING, SETARRIBA, PROG, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, TIMER, PROG, SLEEP, REC HDD, TV/DTV, VARIABLE REPLAY, INFO, VARIABLE, SKIP, EPG, TOP MENU, FAV, OPEN / CLOSE, EJECT, PAUSE, STOP, REC MODE, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DVD, HDD, VCR, SKIP NEXT, SKIP, PREV, .