FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY – ON
AUDIO
MENU / LIST
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
SEARCH MODE
DISPLAY
SLOW
SETUP
PROG UP
PROG DOWN
UP
DOWN
LEFT
RIGHT
ENTER
↵ / RETURN
TIMER PROG.
DUBBING MENU
REC MONITOR
TOP MENU
OPEN / CLOSE - EJECT
PAUSE

STOP
REC MODE
REW
PLAY
FWD
DVD
HDD
VCR
DVD REC / OTR
HDD REC / OTR
VCR REC / OTR
SKIP NEXT
SKIP PREV
VARIABLE REPLAY
VARIABLE SKIP

STANDBY, POWER, AUDIO, MUTE, MENU, / LIST, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / SOURCE, SEARCH MODE, DISPLAY, SLOW, SETARRIBA, PROG, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, TIMER PROG, SLEEP, DUBBING MENU, INFO, REC MONITOR, EPG, TOP MENU, FAV, OPEN / CLOSE, EJECT, PAUSE, STOP, REC MODE, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DVD, HDD, VCR, DVD, REC / OTR, HDD, VCR, SHIIFT+6, SKIP NEXT, SKIP, PREV, VARIABLE REPLAY, VARIABLE SKIP, .