FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
LANGUAGE
ROOT
1/2/3/4/5
6/7/8/9/0
10+
VIDEO SW
GOTO
SETUP
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
STEP
SWITCH
TITLE
ANGLE

PROGRAM
OPEN / CLOSE
PAUSE
STOP
REW
PLAY
FWD
P. SCAN
ZOOM
OSD
PBC
MIC+
MIC -
L / R
N / R
A – B
SLOW
RANDOM

POWER, MUTE, LANGUAGE, MENU, ROOT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 010+, VIDEO SW, GOTO, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, STEP, SLEEP, SWITCH, TV/DTV, TITLE, INFO, ANGLE, EPG, PROGRAM, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, P SCAN, ZOOM, OSD, PBC, MIC+, SHIFT, + VOL, MIC, + VOL, L / R, N / R, SLOW, RANDOM, .