FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
AUDIO
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
AV
P. SCAN
DISPLAY
ZOOM
SETUP
SUBTITLE
SLOW+
SLOW -
PR+
PR -
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
COPY
TV / VCR
TITLE

ANGLE
TV VIEW
OPEN / CLOSE
STOP
REC
REW
PLAY / PAUSE
FWD
TIMER
EDIT
SEARCH
VCR
DVD
SKIP NEXT
SKIP PREV
A – B
REC SPEED

POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV, SOURCE, P SCAN, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, SLOW+, VOL+, SLOW, VOL, PR+, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, COPY, SLEEP, TV / VCR, TV/DTV, TITLE, INFO, ANGLE, EPG, TV VIEW, FAV, OPEN / CLOSE, / NET TV, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY / PAUSE, AMARILLO, FWD, AZUL, TIMER, EDIT, SEARCH, VCR, DVD, SKIP NEXT, SKIP, PREV, REC SPEED, .