FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
VOCAL FADER/MULTIPLEX
SET
CLEAR
1/2/3/4/5
6/7/8/9/0
EDIT / CHECK
+10
GEQ
RANDOM
T-BASS
CLOCK
VOLUME UP
VOLUME DOWN
TUNING UP
TUNING DOWN
DISC DIRECT PLAY 1
DISC DIRECT PLAY 3
DISC DIRECT PLAY 2
KARAOKE ENTER
REPEAT / MONO TUNER
SLEEP
DIRECTION / PRESET
PRGM
OPEN / CLOSE

PAUSE
STOP
REC / REC MUTE
REW
PLAY
FWD
TIMER
CD
VIDEO / AUX
TUNER BAND
TAPE DACK 1/2

POWER, VOCAL FADER/MULTIPLEX, MUTE, SET, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0EDIT / CHECK, / AV, GEQ, RANDOM, BASS, CLOCK, VOLUME ARRIBA, VOL+, VOLUME ABAJO, VOL, TUNING ARRIBA, TUNING ABAJO, DISC DIRECT PLAY 1, DISC DIRECT PLAY 3, IZQUIERDA, DISC DIRECT PLAY 2, DERECHA, KARAOKE ENTER, REPEAT / MONO TUNER, BACK, SLEEP, DIRECTION / PRESET, TV/DTV, PRGM, FAV, OPEN / CLOSE, PAUSE, STOP, REC / REC MUTE, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TIMER, VIDEO / AUX, TUNER BAND, TAPE DACK 1/2, .