FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
SELECT AUDIO
MENU
CANCEL / CH. SKIP
1/2/3/4/5
6/7/8/9/0
SELECT INPUT
CLOCK / COUNTER
VIDEO PLUS+
ONCE
DAILY
WEEKLY
TRACKING+
TRACKING-
CHANNEL+
CHANNEL-
SET+
SET-
SLOW
SPEED
ENTER
COUNTER RESET
AUTO TRACKING
TV / VCR
INDEX

COUNTER MEMORY
T-REC
EJECT
PAUSE / STILL
STOP
REC / OTR
REW
PLAY
F. FWD
AUDIO DUB
PDC
CALL
PRESET
OTPB

POWER, SELECT AUDIO, MUTE, MENU, CANCEL / CH SKIP, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SELECT INPUT, / AV, CLOCK / COUNTER, VIDEO PLUS+, ONCE, DAILY, WEEKLY, TRACKING+, VOL+, TRACKING, VOL, CHANNEL+, CHANNEL, SET+, SET, ABAJO, SLOW, IZQUIERDA, SPEED, DERECHA, ENTER, COUNTER RESET, BACK, AUTO TRACKING, SLEEP, TV / VCR, TV/DTV, INDEX, INFO, COUNTER MEMORY, EPG, REC, FAV, EJECT, PAUSE / STILL, STOP, REC / OTR, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO DUB, PDC, CALL, PRESET, OTPB, .