FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
DVD MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
SEARCH
DISPLAY
RESOLUTION
/ ANGLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
PROGRAM
RANDOM
OPEN / CLOSE
PAUSE / STEP
STOP
SCAN REW
PLAY
SCAN FWD

/ AUDIO
ZOOM
SETUP
/ SUBTITLE
REPEAT
A – B
TITLE
MARKER

T

POWER
AV
VOL+
VOL -
PR / CH+
PR / CH -

POWER, DVD MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SEARCH, DISPLAY, RESOLUTION, / ANGLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, PROGRAM, EPG, RANDOM, FAV, OPEN / CLOSE, / NET TV, PAUSE / STEP, STOP, / SMART, SCAN REW, VERDE, PLAY, AMARILLO, SCAN FWD, AZUL, / AUDIO, MUTE, ZOOM, SETARRIBA, / SUBTITLE, REPEAT, SLEEP, TITLE, INFO, MARKER, VOL+, VOL+, VOL, VOL, PR / CH+, PR / CH, .