FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
CLEAR
1/2/3/4/5
6/7/8/9/0
MUSIC P.
≥10
DISPLAY
DISC
PLAY MODE
VOL+
VOL-
ALBUM – ←
ALBUM – →
ENTER
REPEAT
SLEEP / AUTO OFF
TUNER / BAND
TITLE / SEARCH
PROGRAM
MARKER
TAPE – PLAY
STOP
REW / SKIP PREV.
CD – PLAY/PAUSE

FF. / SKIP NEXT
PRESET EQ.
DEL.
CLOCK / TIMER
H. BASS
INTRO
⏲ – PLAY/REC / DIM.

POWER, MUTING, MUTE, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MUSIC P, / AV, DISPLAY, DISC, PLAY MODE, VOL+, VOL, ALBUM, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP / AUTO OFF, SLEEP, TUNER / BAND, TV/DTV, TITLE / SEARCH, INFO, PROGRAM, EPG, MARKER, FAV, TAPE, PLAY, STOP, REW /, SKIP PREV, VERDE, PLAY/PAUSE, AMARILLO, FF / SKIP NEXT, AZUL, PRESET EQ, DEL, CLOCK / TIMER, H BASS, TV/DTV, INTRO, PLAY/REC / DIM, .