FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
FOLDER
CLOCK / TIMER
DISPLAY
ST / MONO
BASS / TREBLE
EQUALIZER
VOLUME+
VOLUME-
TUNE+
TUNE-
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
P. BASS
DIMMER

MEMORY / PROGRAM
RANDOM
OPNE / CLOSE
STOP
REW / SKIP PREV.
PLAY / PAUSE
FWD / SKIP NEXT
AUDIO IN
BT AUDIO
CD
TUNER
USB
RDS DISPLAY
RDS ASPM
RDS PTY
PRESET+
PRESET-

STANDBY / ON, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FOLDER, / AV, CLOCK / TIMER, DISPLAY, ST / MONO, BASS / TREBLE, EQUALIZER, VOLUME+, VOL+, VOLUME, VOL, TUNE+, TUNE, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, P BASS, TV/DTV, DIMMER, INFO, MEMORY / PROGRAM, EPG, RANDOM, FAV, OPNE / CLOSE, STOP, REW / SKIP PREV, VERDE, PLAY / PAUSE, AMARILLO, FWD / SKIP NEXT, AZUL, AUDIO IN, BT AUDIO, TUNER, USB, RDS DISPLAY, RDS ASPM, RDS PTY, PRESET+, PRESET, .