FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
VCR
DEV. LIST
TIME SHIFT
ZOOM
LANG.
TEXT
V+
V -
CH+
CH -
UP
DOWN
LEFT
RIGHT
ENTER / GROUP
RECALL
TV / RADIO
INFO
EPG

FAV
AUTO
RED /FAV. / DAILY
GREEN / DEL. / WEEK.
YELL. / MOV. / P. INFO
BLUE / LOCK / TIMER
AUDIO
FILE LIST
SUBTITLE
SKIP NEXT
SKIP PREV
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0VCR, SOURCE, DEV LIST, TIME SHIFT, ZOOM, LANG, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER / GROARRIBA, RECALL, BACK, TV / RADIO, TV/DTV, INFO, EPG, FAV, AUTO, / NET TV, ROJO /FAV / DAILY, ROJO, VERDE / DEL / WEEK, VERDE, YELL / MOV / P, AMARILLO, AZUL / LOCK / TIMER, AZUL, AUDIO, FILE LIST, SUBTITLE, SKIP NEXT, SKIP, PREV, PAUSE, STOP, REC, REW, PLAY, FWD, .