FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
/ AUDIO
MENU / LIST
CLEAR
1/2/3/4/5
6/7/8/9/0
AV / INPUT
/ HOME
DISPLAY
ZOOM
PIP
/ SUBTITLE
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
/ RETURN
TIMESHIFT
TV / DVD
TITLE
CHP. ADD
MARKER

OPEN / CLOSE
PAUSE / STEP
STOP
REC
SCAN / REW
PLAY
SCAN / FWD
SEACH
DVD
HDD
PR. / CH+
PR. / CH-
REPEAT
A – B
THUMBNAIL
DUBBING
REC MODE

POWER, / AUDIO, MUTE, MENU / LIST, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV / INPUT, / AV, / HOME, DISPLAY, ZOOM, PIP, / SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, TIMESHIFT, SLEEP, TV / DVD, TV/DTV, TITLE, INFO, CHP ADD, EPG, MARKER, FAV, OPEN / CLOSE, PAUSE / STEP, STOP, REC, ROJO, SCAN / REW, VERDE, PLAY, AMARILLO, SCAN / FWD, AZUL, SEACH, DVD, HDD, PR / CH+, PR / CH, REPEAT, THUMBNAIL, DUBBING, REC MODE, .