FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
DVD / USB / CARD
10+
DISPLAY
ZOOM
TITLE
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SEARCH
CHANNEL
PROG

EJECT
STEP
STOP
F. REV
PLAY / PAUSE
F. FWD
SETUP
RESET
V-MODE
ANGLE
P / N
LANGUAGE
SLOW
/ REPEAT
/ A – B
MARK
PBC
SHUFFLE

STANDBY, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD / USB / CARD, SOURCE, 10+, DISPLAY, ZOOM, TITLE, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SEARCH, INFO, CHANNEL, EPG, PROG, FAV, EJECT, STEP, STOP, REV, VERDE, PLAY / PAUSE, AMARILLO, F FWD, AZUL, SETARRIBA, RESET, MODE, ANGLE, P / N, LANGUAGE, SLOW, / REPEAT, SLEEP, MARK, PBC, SHUFFLE, .