FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
CH. LIST
DISPLAY
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
/ RECALL
SLEEP
TV / RADIO
INDEX
ASPECT
RED

GREEN
YELLOW
BLUE
TIMER
AUDIO
PIC. MODE
S. MODE
REC. LIST
REVEAL
SUBTITLE
SKIP NEXT
SKIP PREV
TIME SHIFT
PAUSE / SUBPAGE
STOP / HOLD
REC
REW
PLAY / SIZE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, CH LIST, DISPLAY, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, / RECALL, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, INFO, ASPECT, / NET TV, ROJO, VERDE, AMARILLO, AZUL, TIMER, AUDIO, PIC MODE, S MODE, REC LIST, REVEAL, SUBTITLE, SKIP NEXT, SKIP PREV, TIME SHIFT, PAUSE / SUBPAGE, STOP / HOLD, REC, REW, PLAY / SIZE, FWD, .