FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STANDBY
MUTING
1/2/3/4/5
6/7/8/9/0
SP. A/B
-/-- / +10 / DIMMER
DISPLAY
D. TUN.
SETUP
VOL+
VOL -
PRESET NEXT
PRESET PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
TUN. MODE
M. GAME / RANDOM
M. MOV./TV / SEARCH
M. MUSIC / REPEAT
M. STEREO / PLAY M.

AUDIO
AUX
BD / DVD
CBL / SAT
TV / CD
VCR / DVR
AM
FM
TV / TAPE
TONE -
TONE+
TONE

ON / STANDBY, POWER, MUTING, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SP A/B, SOURCE, / +10 / DIMMER, DISPLAY, D TUN, SETARRIBA, VOL+, VOL, PRESET NEXT, PRESET PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, TUN MODE, TV/DTV, M GAME / RANDOM, ROJO, M MOV/TV, / SEARCH, VERDE, M MUSIC, / REPEAT, AMARILLO, M STEREO / PLAY M, AZUL, AUDIO, AUX, BD / DVD, CBL / SAT, TV / CD, VCR / DVR, 0TV / TAPE, TONE, TONE+, TONE, .