FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON / STANDBY
MUTING
1/2/3/4/5
6/7/8/9/0
SP A/B
D. TUN.
DISPLAY
SETUP
DIMMER
VOL+
VOL-
SKIP NEXT
SKIP PREV.
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
PAUSE
REW
PLAY
FWD
AUDIO

AUX
DVD
CBL / SAT
GAME / TV
TAPE
TUNER
CD
VCR / DVR
MULTI CH.
VIDEO
CH/DISC -
CH/DISC +
LISTEN. MODE – GAME
LI. MODE – MOVIE/TV
LIST. MODE – MUSIC
LIST. MODE – STEREO

ON / STANDBY, POWER, MUTING, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SP A/B, D TUN, DISPLAY, SETARRIBA, DIMMER, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, PAUSE, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, AUX, DVD, CBL / SAT, GAME / TV, TAPE, TUNER, VCR / DVR, MULTI CH, 0VIDEO, CH/DISC, CH/DISC +, LISTEN MODE, GAME, ROJO, LI MODE, MOVIE, /TV, LIST MODE, MUSIC, STEREO, .